

3gCustomz Bumper Support Installation Guide



3gCustomz Bumper Support Installation Guide

Our Support Plates are meant to install over the OEM Belly Pan. We suggest leaving the plastic belly pan attached to the car if you do not currently have one.

Every model and year will have some little differences therefore we strongly recommend that prior to prep and paint you install your Support Plate and do a test fitment first. Make sure it fits correctly and there no interferences.

Be sure that you have proper clearance on the top, back, sides and bottom and nothing is rubbing.

Use all supplied hardware

While the amount of hardware and mounting location varies by model, these instructions are a general guide for the installation. Pictures may not represent your actual make/model and year.

DISCLAIMER: 3gCustomz LLC cannot control how this product is installed or used. By purchasing this product, the buyer/end user assumes all risks associated with its use and agrees to have the proper skills for its installation. 3gCustomz LLC and its suppliers will not be held responsible, liable or accountable for any injury, damage, loss, penalties, or fines that occur from using this product in any manner.



3gCustomz Bumper Support Installation Guide



1. Remove OEM belly pan
2. Cut away the small section as pictured.
3. Be sure the raised lip on the underside is what is being trimmed



3gCustomz Bumper Support Installation Guide

4. Re-Install the modified Belly Pan, leave the outer 6 bolts out
5. Tuck the Support Plate between the belly pan and bumper
6. Use provided stainless steel bolts to secure plate to cross member
7. Use OEM Hardware to attach Support Plate to Bumper and Belly Pan

